

Document : VC-ED Series Blade replacement procedures

Updated Date: 12-21-09

1) Remove spring hook from blade

The spring hook can be removed by using flat-head screwdriver.
Push underneath the spring for spring hook to be lifted out.



2) Unscrew blade bolt.



3) Disengage blade from handle frame.



4) Insert and secure bolt after blade replacement.



5) Release the blade wide openly and push spring hook back into the hole on the blade.

